Organoid® STONE PINE FOREST on flax fleece **Product** Name Article number ZIRWAL0085FVPRW **Producer** Address **ORGANOID GmbH** Nesselgarten 422 / Top 5 A-6500 Fließ Austria **Description and** Organoid® STONE PINE FOREST on flax fleece Name applications Description Natural plant material in full coverage on natural flax backing produced climate neutral in Tyrol **Applications** As wallpaper As décor, like veneer on backing boards Plant material and Plant material Stone pine wood with moss, spruce needles, grey lichen and fern leaves density Premium density, full coverage Density Size and weight Rolled goods, width 1 360 mm Size Thickness 1,2 mm Weight 430 g/m² **Product requirements** Food-safety Binding agent safe for usage in contact with food in accordance with EU-regulation 1935/2004 **Backing material** Material Non-woven blend of flax and viscose **Properties** Unbleached and breathable from renewable materials Contains 65% flax and 35% viscose Certified OEKO-TEX 100 Tensile strength in accordance with ISO9073-3: MD N/5cm >100 CD N/5cm >70 **Technical** Cut Use scissors, a cutter or a plotter implementation Allow for imperfections 1-2 mm around Edges the edges How to install As wallpaper: • Wall-pasting technique: Apply glue directly on the wall, apply wallpaper vertically and press on using a rubber roller • Double cut: Each panel overlaps with the one next to it (approx. 2 cm)

• Free match: The naturally scattered

between panels

materials do not require matching patterns

As décor:

- Process with normal wood-working machinery
- Glue (e.g. white glue) is applied onto the wooden materials, as the fleece absorbs moisture and glue stains may appear on the front if glue is applied to the fleece
- Cover the natural surface with the enclosed separating paper
- Guidelines:

Max. pressing temperature. 60°C Max. pressure 1 kg/cm²

Glue application: approx. 100 g/m² Pressing time: approx. 15 minutes

Pre-trials and tests are recommended

Glue recommendations

As wallpaper: Glutolin ECC extra clear As décor, like veneer on backing boards: White glue

Pay attention to

Surface must be clean, dry, weight-bearing, evenly absorbent, smooth, dust-free and neutral in colour. Recently plastered walls must be fully dried. Highly absorbent walls must be prepared with a suitable base.

For sensitive wood-working applications, use a counter-balance (enclosed on request). Symmetrical construction is recommended, which means using the same surface on the front and back side.

Acclimatisation of Organoid® natural surfaces:

- Bring product to room temperature before unpacking
- Store product protected from light, at about 20°C and 30-60 % relative humidity.

Storage:

- Rolled goods: hanging system (e.g. paternoster)
- Single panels: horizontal position (e.g. drawer system)

Processing guidelines available at:

www.organoids.com/en/processing