

Organoid® Manual

Version 1.0: May 2025

Recommendations for wall installation of Organoid® Absorber Panels



Wall mounting
Acoustic product

Table of contents

STORING _____	3
PLEASE NOTE _____	3
TOOLS _____	3
HANGING THE PANELS _____	4
HANG THE PANELS IN THE SUBSTRUCTURE WEDGE STRIPS. _____	4
VIDEO TUTORIAL AND PICTURE INSTRUCTIONS _____	4

Storing

Bring to room temperature before unpacking. Store product in closed, dry rooms, at a normal temperature and protected from light (at about 20°C and 30-60 % relative humidity).

Please note

In case any anomalies and/or defects occur, Organoid® has to be contacted in written form immediately. Please check before installation if the delivery has any anomalies and/or defects.

Natural surfaces by Organoid® are made from natural plant fibres, therefore individual products of the same type may vary in colour, smell, or texture. Allow for the dimensions of the surfaces to vary up to +/- 2%, as they are unavoidable from a technical point of view. Small deviations due to these biological properties are therefore not a reason for complaint or warranty claims.

Tools

Recommended tools:

- Drill
- Screws and wall plugs - depending on the condition of the wall
- Spirit level
- Measuring tape or metre rule
- Pencil

Fastening the substructure

Absorber panel: width 1,300 mm without groove, without insulation, suspension with wedge strips

- Screw the screws into the moulding of the substructure so that approx. 3-5 mm of the screw tip protrudes.
- Align the moulding exactly horizontally using a spirit level.
- Press the slightly protruding screws against the wall to make precise marks for the dowel holes.
- Drill the holes and insert the wall plugs: Select the wall plugs and screw length according to the condition of the wall.
- Measure the distances between the wedge strips attached to the panel and transfer these measurements to the wall.
- Attach the remaining substructure strips as described above.
- Use a spirit level to check that both the lateral and horizontal alignment is correct.

Hanging the panels

Hang the panels in the substructure wedge strips.

Video tutorial and picture instructions











